
## Siphon for softeners


A siphon set with air gap at the wastewater draining off from the softener

## Assembly of the siphon

The siphon set comprises 9 elements (**fig. 1**): the siphon, an elbow, pipe, 2 nuts, 2 seals and 2 washers. Place the nuts onto the pipe and then place the washers and nuts as showed on **fig. 2**. Connect one end of the siphon with the pipe and the second with the elbow and tighten the nuts. The assembled siphon should look like on **fig. 3**.









## Assembly of the air gap with the siphon

The air gap comprises 2 elements (fig. 4): the valve (white) and adapter to the drain hose (grey element). Insert the adapter into the valve with the smooth side of the adapter (fig. 5). Put the bottom part of the valve into the siphon pipe (fig.6). Use glue for plastic material. Check for any leaks. Connect the adapter with the drain hose. Check again for any leaks.





